



## QUICK INSTALLATION GUIDE

# EX PHONO 2X

### Introduction

The optional EX PHONO 2X module is a dedicated pre-amplifier that will allow you to connect your turntable to your BC components. The EX PHONO 2X is compatible with MM (Moving Magnet) and MC (Moving Coil) cartridges.

The EX PHONO 2X module is compatible with the following models: EX222.1 - EX202.1. On the rear side of its models, a 12V output will supply power to the module.

#### INSIDE THE PACKAGING

- 1x EX PHONO 2X card
- 1x Stereo RCA cable
- 1x 3 pins MOLEX cable / POWER 12V
- 1x This quick installation guide




Stereo RCA cable

Power cable  
3 pins Molex

Note: No tools are required to connect the card to your amplifier and turntable.

### Phono card MM & MC



### Important safety instructions

**You do NOT NEED TO OPEN your amplifier to connect your EX PHONO 2X card**

Before starting the installation of the EX PHONO card, make sure that your amplifier EX Series is powered off AND disconnected from the wall power cord.


We invite you to contact our accredited service stations if your product has been chocked, exposed to moisture or humidity or if any parts has been introduce inside the product. Internal fuses replacement is also an operation which should be done by accredited technician.

### IMPORTANT !

PLEASE FOLLOW THESE STEPS IN THE ORDER INDICATED


## Quick installation guide

- 1- Turn off the amplifier.
- 2- Remove the power cord from the amplifier.
- 3- Connect using a stereo RCA cable the output of your turntable to the "PHONO IN" input of the EX PHONO 2X card.



Note: Depending on the cell of your turntable, adjust the selector to MM (moving magnet) or MC (moving coil).

- 4- Using the RCA stereo cable supplied with the card, connect the "LINE OUT" output of the card to a stereo RCA inputs on your amplifier.



- 5- Connect the 3 pins cable supplied with the card on "12V POWER" input, and the "optional board power" output of your dedicated amplifier.



- 6- Connect the power amplifier cord, turn on the amplifier and select the input to which you connect your turntable using the EX PHONO 2X card and enjoy the sound!

## Troubleshooting

For repair, during or after the warranty, please contact your dealer.

To obtain warranty service and technical support, thank you kindly to register your product online on the website [www.bc-acoustique.com](http://www.bc-acoustique.com) at the product registration section.



BC ACOUSTIQUE  
BP 306  
94709 Maisons-Alfort Cedex France  
[www.bc-acoustique.com](http://www.bc-acoustique.com)