

AX-501 - IR CODES

	0 x 8 1 7 3	0 x 8 0 7 2
00		FF SKIP (>>)
01		SHUFFLE
02		
03		
04		REW SKIP (<<)
05	VOLUME+	
06	VOLUME-	REVIEW (<<)
07		CUE (>>)
08	MUTING	PLAY/PAUSE
09		STOP
0A		
0B		
0C		REPEAT
0D		
0E		
0F		
10	LINE1	
11	USB	
12	LINE2	
13		
14		
15		
16	METER(DIMM)	

0x00 - 0x16 of vertical is key code